








# Areza

Installation manual – UltiLED, OptiT8 and T5

DIMENSIONS	LENGTH (mm)	WIDTH (mm)	HEIGHT (mm)	C-C (mm)	WEIGHT (kg)
	660	101/145	108	370-410	1,4-2,2*
	1277	101/145	108	780-820	2,0-3,2*
	1573	101/145	108	1080-1120	2,9-4,0*

\* Depending on version / abhängig von der jeweiligen Ausführung / dépendre de modèle



- UK Disconnect the unit before changing the lamp.
- F Débrancher l'appareil avant de changer la lampe.
- D Vor Austausch der Lampe Leuchte spannungsfrei schalten.



